







Shupatto

○Specifications

Products	Size	Volume	Capacity	Material	Functions
Shupatto Packable Bag 8 L		8 L	3 kg 6.6 lb	Bag / Polyester (Water Repellent) Handle / Polyester	Water Repellent 
Shupatto Packable Bag 27 L		27 L	10 kg 22 lb	Bag / Polyester (Water Repellent) Handle / Polyester	Water Repellent 


Made in China

○How to Fold Shupatto

• Shupatto Packable Bag 8 L



Hold the tapes of both ends and ...



Pull




Fold in half twice




Roll it up and store it in the attached pouch


• Shupatto Packable Bag 27 L




Hold the tapes of both ends and ...



Pull



Fold in half twice



Roll it up and store it in the attached pouch

○Precautions for Use

- Children should not use this product without supervision.
- Do not hang this bag for too long with heavy objects inside.
- This bag can be damaged when dragged or with sharp objects inside.
- Some color loss on this bag may be caused when it has just begun to be used and when in contact with wet objects.
- Do not use this product outside of its intended purpose.

○Product Care

- Fold this bag down immediately after use.
- If the pleats do not fold in neatly, fold it after straightening the pleats along the pleat lines.
- If the bag gets dirty, dip a soft cloth into a diluted synthetic detergent (laundry detergent, soap, etc.), tightly wring the cloth, and then wipe the surface of the bag by tapping.
- Machine washable (Max. temp.: 30 °C).
Use a laundry net and wash separately.
- Laundering will remove the water-repellent finish.
After laundering, use a commercial water-repellent spray.
- Do not use chlorine bleach, fabric softener, dryer, or iron.
- Do not soak.
- After washing, straighten the bag along the pleat lines and flat dry in an airy shade.